Aussie Home Energy – *Helping You Monitor Reduce & Save On Electricity Costs*

Quick Help Guide For Home Electricity Monitor Button Functions

1. Pressing the UP or DOWN arrow buttons, changes between appliances, ie between transmitters.

2. Pressing the OK button, changes the data displayed from one, to seven or 30 days.

3. Press, hold and release the OK button after 3 seconds, to set the clock.

4. Press, hold and release the UP arrow button after 3 seconds, to set the currency rate.

5. Press, hold and release the UP & DOWN arrows together, to set the low tariff price and start times.

6. Press, hold and release the OK & DOWN arrow button to download the monitors history to the computer. Please note: all of the monitors processor activity is halted during this download, even the clock. Where there is a lot of history, the download may take some time! Self-resets when done.

7. Press, hold and release the UP arrow during power-up, to display the whole of the LCD's possible display options for two seconds. The software version is then displayed. The monitor will need to be turned off to remove the software revision. Power on again for normal use.

8. Press, hold and release the UP & DOWN arrows during power-up to delete all History and Tuning IDs and burn in fresh defaults. Data is not physically erased, only the pointers are quickly set to zero.